



Item P25-0630

Mr. Clean Magic Eraser

The cleaning pad's microscrubbers reach i nto the surface grooves, lifting away built up dirt and grime. It removes more grime per swipe vs. the leading all-purpose bleach spray cleaner.

Item	Description	Attributes
25-0630	7 Pack	