



Item P25-0496

Boot & Shoe Brush

Helps eliminate dirt, bacteria and other contaminants from being tracked through buildings, job trailers, clean areas, and food preparation areas. Chrome steel frame can be securely bolted to the floor for security and convenience. Brushes flip up to expose a steel scraper for removing heavy debris and mud from the bottom of shoes. Non absorbent plastic block has long lasting, blue polypropylene bristles.

Item	Description	Attributes
25-0496	Boot & Shoe Brush Complete	
25-0498	Replacement Brush Only	