



**Item P10-2377**

**Bosch 18V 3-1/4 In. Planer (Bare Tool)**

The Bosch PLH181 planer is great for fast stock removal and leaves a smooth finish. This planer is ideal for trimming doors, and because it is cordless, it eliminates the possibility of running out of cord in the middle of a planing pass. The electronically counterbalanced single-blade system automatically positions the blade at the ideal cutting angle, and it eliminates uneven planing caused by misaligned blades. The planer comes with a guide fence that can be mounted to either side of the tool. Battery and charger sold separately.

Item	Description	Attributes
10-2377	PLH181B 18V 3-1/4 In. Planer (Bare Tool)	